

# LAWRENCEVILLE



Stacking Option: Yes

Hardwood Species: Beech, Ash, Cherry,  
Red Oak, Maple, White Oak


Arms: With or without

Seat Type: Wooden or Upholstered

Warranty: 20 years

Construction: Eustis Joint

## Chair Dimensions



Height (H):	39"
Chair Width (CW):	17.5"
Seat Depth (SD):	16.8"
Sitting Height (SH):	18"
Front Width (FW):	18"



978-827-3103 • [sales@eustischair.com](mailto:sales@eustischair.com) • [EustisChair.com](http://EustisChair.com)

